


**BOSCH**

SMS5011/03-EU1
 SMS5011ZA/03-ZA1
 SMS5011IL/03-IL1

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740

51 3598
Gebrauchsanweisung
 (D,F,GB,I,NL)
51 3779
Montageanweisung
 (D,F,GB,I,NL,DK,
 E,P,S,N,SF,GR,TR)




- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944 Set
- 6) —
- 7) —
- 8) —
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set

**BOSCH**

SMS5011/03-EU1
 SMS5011ZA/03-ZA1
 SMS5011IL/03-IL1

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740




- 1) 10 4298
PVC Ø5mm/2m
- 2) 02 5069
Set
- 3) 02 7375
- 4) 02 9948
- 5) 02 9017
Set
- 6) 05 6826
- 7) 05 6827
- 8) —
- 9) 05 6806
- 10) 02 2480
65°
- 11) 02 9953
50°C

**BOSCH**

SMS5011/03-EU1
 SMS5011ZA/03-ZA1
 SMS5011IL/03-IL1

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740



**BOSCH**

SMS5011/03-EU1
SMS5011ZA/03-ZA1
SMS5011IL/03-IL1

GESCHIRRSPÜLGERÄTE
Standgeräte

Ident – Nummern – Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247

