




Ident – Nummern – Konstante	
3740	

Gebrauchsanweisungen:

51 4027

(D)

51 4028

(NL,F,E,GB)

51 4029

(D,F,I)

51 4030

(S, DK)

Programmtabellen:

51 4031

(D)

51 4032

(NL)

51 4033

(F)

51 4034

(E)

51 4035

(GB)

51 4036

(1)

51 4037

(S)

Aufstellanweisungen:

51 3556

(D,I,S,N,SF)

51 3557

(S.D.K)

51 3558

(NL.F.E.GB)

1) 08 8739

(D.I)


08 8740


00 074
(NL.F)


08 8769

08 8769
(S DK)

(S,DK)

**BOSCH**WFS7000-WFS7000/03-D1
WFS7000-WFS7000FG/03-FG1WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740

**BOSCH**WFS7000-WFS7000/03-D1
WFS7000-WFS7000FG/03-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
37401) 27 1716
15 5272
Triac-Motorleistung

**BOSCH**WFS7000-WFS7000/03-D1
WFS7000-WFS7000FG/03-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740