


**BOSCH**

WFS8300-WFS8300/03-D1
WFS8300-WFS8300CH/03-CH1

WASCHGERÄTE
Waschvollautomaten



Ident – Nummern – Konstante
3740

Gebrauchsanweisungen:

51 4027

(D)

51 4028

(NL,F,E,GB)

51 4029

(D,F,I)

51 4030

(S,DK)

Programmtabellen:

51 4031

(D)

51 4032

(NL)

51 4033

(F)

51 4034

(E)

51 4035

(GB)

51 4036

(I)

51 4037

(S)

Aufstellanweisungen:

51 3556

(D,I,S,N,SF)

51 3557

(S,DK)

51 3558

(NL,F,E,GB)

1) 08 8739


(D,I)


08 8740


(NL,F)

08 8769

(S,DK)

**BOSCH**WFS8300-WFS8300/03-D1
WFS8300-WFS8300CH/03-CH1WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740

**BOSCH**WFS8300-WFS8300/03-D1
WFS8300-WFS8300CH/03-CH1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
37401) 27 0444
15 5272
Triac-Motorleistung

**BOSCH**WFS8300-WFS8300/03-D1
WFS8300-WFS8300CH/03-CH1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740



BOSCH

WFS8300-WFS8300/03-D1
WFS8300-WFS8300CH/03-CH1

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740

