


**BOSCH**

WFK6000-WFK6000/04-D1
 WFK6000-WFK6000FG/04-FG1
 WFK6000-WFK6000SI/04-SI1

WASCHGERÄTE
 Waschvollautomaten



Ident - Nummern - Konstante
 3740

- 1) 08 6336
 (D)
- 08 6337
 (NL)
- 08 6338
 (N)
- 08 6339
 (SF)
- 08 6340
 (S)
- 08 6341
 (E)
- 08 6342
 (F)
- 08 6343
 (DK)
- 08 6344
 (I)
- 08 6686
 (TR,YU,E,GB)
- 08 6690
 (GB)

Gebrauchsanweisungen:

- 51 3566
 (D,I,S,N,SF)
- 51 3567
 (S,DK)
- 51 3568
 (NL,F,E,GB)

Programmtabellen:

- 51 3552
 (D)
- 51 3553
 (I,S,N,SF)
- 51 3554
 (S,DK)
- 51 3555
 (NL,F,E,GB)

Aufstellanweisungen:

- 51 3556
 (D,I,S,N,SF)
- 51 3557
 (S,DK)
- 51 3558
 (NL,F,E,GB)




BOSCH

WFK6000-WFK6000/04-D1
WFK6000-WFK6000FG/04-FG1
WFK6000-WFK6000SI/04-SI1

WASCHGERÄTE
Waschvollautomaten


Ident - Nummern - Konstante
3740

**20 4245
Unterbauabdeckung**



Ident - Nummern - Konstante
 3740

1) 27 1716
 15 5272
 Triac-Motorleistung



Ident - Nummern - Konstante
3740

