




Ident – Nummern – Konstante
3740

1) 08 6336
(D)
08 6337
(NL)
08 6338
(N)
08 6339
(SF)
08 6340
(S)
08 6341
(E)
08 6342
(F)
08 6343
(DK)
08 6344
(I)
08 6686
(TR,YU,E,GB)
08 6690
(GB)

Gebrauchsanweisungen:

51 3566
(D,I,S,N,SF)
51 3568
(NL,F,E,GB)

Programmtabellen:

51 3552

(D)

51 3967

(D,I,S,N,SF)

51 3555

(NL, F, E, GB)

Aufstellanweisungen:

51 3968


(D,I,S,N,SF)


51 3969

(NL, F, E, GB)

2) 27 1636

Blende kompl.

**BOSCH**WFK7310-WFK7310/01-D1
WFK7310-WFK7310FG/01-FG1WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740

**BOSCH**WFK7310-WFK7310/01-D1
WFK7310-WFK7310FG/01-FG1WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
37401) 27 1716
15 5272
Triac-Motorleistung



BOSCH

WFK7310-WFK7310/01-D1
WFK7310-WFK7310FG/01-FG1

WASCHGERÄTE
Waschvollautomaten

Ident – Nummern – Konstante
3740

