




Gebrauchsanweisungen

51 1910/00

D1

(D,GB,F,I,NL)


51 1911/00

F1

(F)

1) 05 0642/08
kompl.

2) 08 4369/03
D1
08 4370/03
F1



TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Matsushita		
Typ/Type		FN 91 Q 17 G		
Förderleistung/Delivery/Débit	l/h	V 1633		
Anlaufstrom/Starting current/Cour. de démarrage	A	11,7		
Widerstand/Resistance/Résistance	Ω	8,6		
	Hi/aux	30,5		
Temp.-Regler/Thermostat		Ranco		
Typ/Type		K 54		
Reglerstellung/Position		kalt	warm	
Schaltwerte/Switching values/	„ein“ °C	- 24	- 18	
Valeurs de commutation	„aus“	- 31	- 24	
	(„abtauen“ od.) „alarm“	- 19	- 14	
Füllmenge/Fill.quantity/Charge	R12	g	200	
Anschlußwert/Conn.load/Puiss. connectée		W		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω	155		
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			

Pos.				
	Matsushita			
1	14 0318/47			
2				
3	02 6742/21			
4				
5				
6	05 4733/03			
7	02 6731/01			
8				
9	01 3486/01			
10				
11				
12				
13				
14				