





Gebrauchsanweisung
51 3926
(D,F,GB,I,NL)
Kurzanweisung
51 3927
(D)
Kochbuch
51 3930
(D)


Zubehör:

Einbaurahmen
HZ 67040
kratzfeste Abdeckung
HZ 67740
Alu-Backblech
HZ 8055
Glaspfanne
HZ 8056
Glasbräter
HZ 9150

- 1) 03 0681
grün
- 2) 03 0691
umbra
- 3) 03 0679

- 1) 03 0671
2) 03 0813
Arretierstift





- 1) 11 4538
Backblech
- 2) 11 4539
- 3) 11 4537
Glasschale
- 02 8732
Anschlag-backblech

