




Gebrauchsanweisung:
51 4839
(D)

Aufstellanweisung:
51 4750
(D,GB,F,I,NL,E)

Programmtabelle:
 51 4753
 (NL,F,E,GB)
 51 4754
 (D,I,SF,N,S)

1) 28 2622
Blende kompl.

- 2) 03 2288
- 3) 05 9694
- 4) 05 9344 1)

