


HF74240/01-D1,umbra
HF74240/02-D2,umbra
HF74240NL/01-NL1,umbra
HF74240NL/02-NL2,umbra

HF74240FF/01-F1,umbra
HF74240FF/02-F2,umbra
HF74240GB/01-GB1,umbra
HF74240GB/02-GB2,umbra

HF74240CH/01-CH1,umbra
HF74240CH/02-CH2,umbra
HF74240BB/01-B1,umbra
HF74240BB/02-B2,umbra

HERDE
Mikrowellenherde



Gebrauchsanweisung

51 5864
(D,GB,F,I,NL)
51 5862
(CH,10A)
51 6144
(GB,10A)

Kochbuch

51 5729
(D)
51 5853
(F)
51 5849
(NL)
51 6252
(GB)

Kurzanweisung

51 6004
(D)

Lüfternachlauf:


05 8370
GB1,GB2

Zubehör:

Einbaurahmen
HZ 67040
kratzfeste Abdeckung
HZ 67740
Alu-Backblech
HZ 8055
Glaspfanne
HZ 8056
Glasbräter
HZ 9150

- 1) 03 0681
grün
- 2) 03 0691
- 3) 03 0679

- 1) 03 0671
2) 03 0813
Arretierstift





HF74240/01-D1,umbra
HF74240/02-D2,umbra
HF74240NL/01-NL1,umbra
HF74240NL/02-NL2,umbra

HF74240FF/01-F1,umbra
HF74240FF/02-F2,umbra
HF74240GB/01-GB1,umbra
HF74240GB/02-GB2,umbra

HF74240CH/01-CH1,umbra
HF74240CH/02-CH2,umbra
HF74240BB/01-B1,umbra
HF74240BB/02-B2,umbra

HERDE
Mikrowellenherde





- 1) 08 7498
mitbestellen
- 2) 09 2690
- 3) 05 8148
D1,D2,NL1,NL2,
F1,F2
B1,B2
30 Ohm
06 5930
GB1,GB2,CH1,CH2