




Aufstellanweisungen:

51 3556

(D,I,S,N,SF)

51 3557

(S,DK)

51 3558

(NL,F,E,GB)

Gebrauchsanweisungen:

51 4933

(D)

51 5181

(NL,F,I,GB)

51 5303

(SF.N)

51 5304

(D,F,I,S)

Programmtabellen:

51 4932

(D)

51 5182

(NL)

51 5183

(F)

51 5184

(1)

51 5185

(GB)

51 5305

(S)

51 5306

(SF)


51 5307

(N)

1) 27 7932

Blende kompl.

FG1



Zubehör:
Verlängerung für
Arbeitsplatten:
WZ 10040
weiß
Bodenbefestigung:
WX 9756
Höhenanpassung 91 cm:
WZ 10100
Wärmeschutz/
Kindersicherung:
WZ 10110

