






**BOSCH**

SMS3072/03-EU1, weiss


GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
3740

**BOSCH**

SMS3072/03-EU1, weiss

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740

- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

Ident - Nummern - Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247