


**BOSCH**


SMS3042AU/08-AU1, weiss


GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
3740

51 4729
EU1,I1
Gebrauchsanweisung
(D,F,GB,I)
51 3779
Montageanweisung
(D,F,GB,I,NL,DK,
E,P,S,N,SF,GR,TR)



- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944 Set
- 6) —
- 7) —
- 8) —
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set
- 13) —
- 14) 02 9013 gelb
02 9011 rot



Ident – Nummern – Konstante
3740

Ident – Nummern – Konstante
3740