


**BOSCH**

SMS3042AU/01-AU1


GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
3740

51 4729
EU1,I1
Gebrauchsanweisung
(D,F,GB,I)
51 3779
Montageanweisung
(D,F,GB,I,NL,DK,
E,P,S,N,SF,GR,TR)






Ident - Nummern - Konstante
3740





Ident – Nummern – Konstante
3740



- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

Ident – Nummern – Konstante
3740