




Aufstellanweisungen:

51 3556
(D,I,S,N,SF)
51 3557
(S,DK)
51 3558
(NL,F,E,GB)

Ident – Nummern – Konstante	
3740	

1) 08 6336
(D)
08 6337
(NL)
08 6338
(N)
08 6339
(SF)
08 6340
(S)
08 6341
(E)
08 6342
(F)
08 6343
(DK)
08 6344
(I)
08 6686
(TR,YU,E,GB)
08 6690
(GB)


Gebrauchsanweisungen:

51 3566
(D,I,S,N,SF)
51 3567
(S,DK)
51 3568
(NL,F,E,GB)

Programmtabellen:

51 3552
(D)
51 3553
(I,S,N,SF)
51 3554
(S,DK)
51 3555
(NL,F,E,GB)

Ident – Nummern – Konstante
3740




**BOSCH**

WFK4000-WFK4000/01-D1
 WFK4000-WFK4000FG/01-FG1
 WFK4000-WFK4000SI/01-SI1

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740

1) 11 9901
 15 5272
 Triac-Motorleistung



**BOSCH**

WFK4000-WFK4000/01-D1
WFK4000-WFK4000FG/01-FG1
WFK4000-WFK4000SI/01-SI1

WASCHGERÄTE
Waschvollautomaten

Ident - Nummern - Konstante
3740

