

Ident – Nummern – Konstante
3740

51 5322
Gebrauchsanweisung
(S,N,SF)
51 3842
Montageanweisung
(D,F,GB,I,NL,DK,
E,P,S,N,SF,GR,TR)

- 1) 02 9944
Set
- 2) 05 6823
Set
- 3) 02 9673
- 4) 02 7091

| Zubehör:


**Silberbesteck-
korb
SMZ 2003**


Steck-Etagere SMZ 2006


**Korbeinsatz
SMZ 2004**

Unterbausockel SMZ 3006


**Verl.Aqua-Stop
SMZ 3005
Kupferrohr
SMZ 3008
Schl.Aqua-StopII**




 Ident - Nummern - Konstante
3740


Ident - Nummern - Konstante
3740

- 1) 05 4927
- 2) 11 9082
- 3) 05 6829
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

Ident - Nummern - Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247