


**BOSCH**

SMI4026CH/01-CH1
SMI4026CH/02-CH2
SMI4026CH/03-CH3
SMI4026CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte


Ident - Nummern - Konstante
3740

51 3601
Gebrauchsanweisung
(D,GB,F,I,NL)
51 3842
Montageanweisung
(D,GB,F,I,NL,DK,
E,P,S,N,SF,GR,TR)




- 1) 02 9941
- 2) 02 9029
- 3) 11 9996
- 4) 05 6860
- 5) 02 9944 Set
- 6) 05 6823 Set
- 7) 02 9673
- 8) 02 7091
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set

Ident – Nummern – Konstante
3740



Ident – Nummern – Konstante	
3740	



- 1) 05 4927
- 2) 11 9082
- 3) 05 6829
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889
- 8) 05 7134
CH1,CH2
02 9199
CH3,CH4

**BOSCH**

SMI4026CH/01-CH1
SMI4026CH/02-CH2
SMI4026CH/03-CH3
SMI4026CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident – Nummern – Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247

