


Ident - Nummern - Konstante
 3740



Gebrauchsanweisung
 51 3869
Bratzeit-Automatik-
Wählscheibe
 51 3359
 D1, D2, D3
 (D, F, GB, I, NL)

Tips und Rezepte
 51 3819
 D1, D2, D3
 (D)
 51 1563
 B1
 (NL)


- 1) 03 0389
- D1
- 030392
- D2
- 03 0540
- D3
- 03 1387
- B1
- 2) 05 6735

**BOSCH**


HEE650U/01-D1, braun
 HEE652U/01-D2, weiß
 HEE653U/01-D3, grau
 HEE656UBL/01-B1, braun

HERDE
 Einbau-Herde

Ident - Nummern - Konstante
 3740



- 1) 11 6752
 D1
 11 6846
 D2
 11 7770
 D3
 27 1316
 B1
- 2) 70 7255
 63mA/T
- 3) 02 8631
 Set
- 4) 03 0405
 Kompl.
- 5) 11 6753
 D1
 11 6847
 D2
 11 7771
 D3
 27 0562
 B1



- 1) 11 1284
Rost
- 2) 11 1270
Spritzschutz
- 3) 11 1286
Backblech
- 4) 11 4891
Kombipfanne
11 1285
Bratpfanne
Sonderzubehör