


**BOSCH**

HEE650U27/01-SF1, braun
 HEE650U27/01-SF2, weiss
 HEE650U35/01-N1, weiss
 HEE650U65/01-S1, weiss

HEE650UFD/01-FD1, weiss

HERDE
 Einbau-Herde



Mat. - Nr. - Konstante
 3740

Gebrauchsanweisung

51 3883
 N1, SF1, SF2
 (N, SF, S)
 51 4600
 FD1
 (SK, DK)

Montageanleitung

51 4303
 N1, SF1, SF2, S1, FD1
 (N, SF, S)

1) 03 0389
 SF1
 03 0392
 N1, SF2, FD1
 03 1386
 S1

2) 05 6735

Tips und Rezepte


51 2988
 N1
 (N)

**BOSCH**

HEE650U27/01-SF1, braun
 HEE650U27/01-SF2, weiss
 HEE650U35/01-N1, weiss
 HEE650U65/01-S1, weiss

HEE650UFD/01-FD1, weiss

HERDE
 Einbau-Herde



Mat. - Nr. - Konstante
 3740


- 1) 11 6752
SF1
11 6846
N1, SF2, S1
27 0973
FD1
- 2) 70 7255
63 mA/T
- 3) 02 8631
Set
- 4) 03 0405
kompl.
- 5) 11 6753
SF1
11 6847
N1, SF1, SF2, S1
27 0974
FD1

**BOSCH**

HEE650U27/01-SF1, braun
 HEE650U27/01-SF2, weiss
 HEE650U35/01-N1, weiss
 HEE650U65/01-S1, weiss

HEE650UFD/01-FD1, weiss

HERDE
 Einbau-Herde



Mat. - Nr. - Konstante
 3740

- 1) 11 1284
Rost
- 2) 11 1270
Spritzschutz
- 3) 11 1286
Backblech
- 4) 11 4891
Kombipfanne
- 11 1285
Bratpfanne
- Sonderzubehör