




Ident – Nummern – Konstante
3740

Gebrauchsanweisung
58 4259

1) 17 3891
V01,V02,V03
42 4423
V04,V05,V06.V07
V08,V09,V10,V11
V12

2) 41 8119

3) 26 7356

4) 26 7357

5) 26 7359

6) 18 8756

7) 18 3762


8) 36 2414

9) 17 3896

10) 17 3897

11)17 3898

58300000085094_AET_000_J -2/1



Ident - Nummern - Konstante
 3740

- 1) 16 9339
- 2) 17 3894
- 3) 17 3895
- 4) 48 4339
- V01
- 48 9635
- V02
- 49 0728
- V03,V04,V05,V06
- V07,V08,V09,V10
- V11,V12
- 5) 49 4151
- V05,V06,V07,V08
- V09,V10,V11,V12

Duesensatz Für:
 EG H/E G20 20mbar
 17 4049

FG G30/31 30mbar
 17 4048

EG H/E G20 20mbar
 (inkl.Bypassdusen)
 41 7597

EG LL G25 25mbar
 (inkl.Bypassdusen)
 41 8134

FG G30/31 30mbar
 (inkl.Bypassdusen)
 41 7837