




Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
58 3671
(da,sv,no,fi)

Montageanweisung
52 4904
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HEZ1004
Backblech Alu
HEZ1101
Backblech emailliert
HEZ1301
Universalpfanne
HEZ1401
Kombirost
HEZ2400
Einlegerost
HEZ1710
Teleskopauszug
3-fach
HEZ1711
Teleskopauszug
Vollauszug
HEZ1712
Teleskopauszug
2-fach
HEZ1700
Profi-Auszug
HEZ4701
Deckel-f. Profipfanne

1) 01 4254







Mat. - Nr. - Konstante
3740


1) 48 2981
Set

Zubehoer:
HEZ2500
Grillblech
HMZ21GB
Glasbraeter
HEZ6000
Metallbraeter
HEZ5052
Tuergriff Edelstahl
HEZ5072
Tuergriff Alu
HEZ6001
Backform
Auslaufsicher






Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740