




Gebrauchsanweisung
52 6399
(DE,GB,FR,IT,NL
PT,ES)


- 1) 17 2761
- 2) 17 2762
- 3) 17 2579
- 4) 17 2259
- 5) 26 6670
- 6) 17 2574
- 7) 17 2575





- 1) 17 2274
- 2) 06 0115
- 3) 06 0083
- 4) 35 9220
- 5) 35 9217
- 6) 35 9219





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNICUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor	ASPERA			
Typ/Type/Tipo	NBT 1118Y			
Förderleistung/Delivery/Debit/Aspiración l/h	2574			
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	-			
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	11.0			
	Hi/aux. 16.4			
Klape Therm./Thermostat/Termostat				
Typ/Type/Tipo				
Reglerstellung/Position/Conexión				
Schaltwerte/Switching values/	..ein/conex. °C			
Valeurs de commutation/Desconex.	..aus"/descon.			
(..abtaven' od)	..alarm'			
Füllmenge/Fill. quantily/Charge/Carga R600	g	45		
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	150		
Heizung/Heater/Chauflage/Resistenc. descong.		Verdampfer	Ablaufrinne	Luftkanal
Widerstand/Resistance/Resistencia	KΩ	0.38	1.4	13.49
Leistung/Power/Puissance/Potencia	W	145/230	37.5/230	4/230
Ventilador/Blower/Ventilateur/Ventilador		Verdichter	Verdampfer	
Widerstand/Resistance/Resistencia	KΩ	0.61	0.41	