




Page/Item	Part No.	Image	Part Discription
01 01	14 2901	PANEL	BACKSPLASH R/A KHS30QS
01 01	V01, 14 2902	PANEL	BACKSPLASH R/A KHS36QS
01 01	V02, 14 2903	PANEL	BACKSPLASH R/A KHS482QS
01 01	V03, 14 3114	PANEL	BACKSPLASH R/A KHS48QS
01 01	V04, 14 2904	PANEL	BACKSPLASH R/A KHS54QS
01 01	V05,		
01 02	36 7635	SHELF	RACK, KEEP HOT
01 03	41 2296	CLIP	CLIP, RACK TOP
01 04	41 2297	CLIP	CLIP, RACK BTM
01 05	42 0133	SCREW	Screw
01 06	18 9417	SCREW	SCREW, 6 X 1/2 " PH
01 07	41 5586	RIVET	RIVET 1/8X3/16 SS
01 08	41 3759	BRACKET	BRACKET, BACKSPLASH STIFF

* Not illustrated