



Burner Box Assembly



Page/Item	Part No.	Image	Part Description
01 01	369108	PLATE	SHIELD, HEAT-CTRL PNL LWR
01 02	415360	KNOB	KNOB, DUAL ELEM BLK
01 02	415361	KNOB	KNOB, DUAL ELEM WHT
01 04	415362	KNOB	KNOB, SGL ELEM BLK
01 04	415363	KNOB	KNOB, SGL ELEM WHT
01 06	487637	FRAME	TRIM, CTRL PNL MIDDLE BLK
01 06	485707	FRAME	TRIM, CTRL PNL MIDL BRSH
01 08	487632	FRAME	TRIM, CONTROL PANEL LWR B
01 08	487633	FRAME	TRIM, CONTROL PNL LWR SS
01 10	415456	COVER	ENDCAP, CONTROL PANEL RT
01 10	415461	COVER	ENDCAP, CONTROL PANEL LT
01 10	415459	COVER	ENDCAP, CONTROL PANEL LT
01 14	415457	COVER	ENDCAP, CONTROL PANEL LT
01 14	415460	COVER	ENDCAP, CONTROL PANEL RT
01 16	486751	INSTALLATION SET	KIT-CONTROL BUTTON 30" RNG
01 18	411358	WASHER	GROMMET, BLK
01 18	411359	WASHER	GROMMET, WHT
01 19	142468	PANEL	GLASS, CTRL PNL BLK REF/S
01 19	484746	PANEL	GLASS, CTRL PNL GRY REF/S
01 19	484745	PANEL	GLASS, CTRL PNL WHT REF/S
01 22	487577	PLATE	PLATE, CNTRL MNTG 30" RNG
01 23	486752	INSTALLATION SET	KIT-ERC III CONTROL (30" R
01 24	189969	SWITCH	SWITCH, LIGHT W/TERM
01 25	411223	LAMP	LIGHT, INDICATOR
01 26	414607	SWITCH	SWITCH, INFINITE (30" RNG)
01 27	189808	SWITCH	SWITCH, DUAL COIL
01 30	414634	REGULATOR-TEMPERATURE	THERMOSTAT, CV
01 31	414635	REGULATOR-TEMPERATURE	THERMOSTAT, VAC
01 32	411175	SPACER	SPACER, .250 OD x .596
01 33	368142	COVER	COVER, CTRL
01 34	367849	CLIP	CLIP, HOLD-DOWN
01 35	485768	BRACKET	BRACKET, VAC SWITCH
01 37	368125	COVER	COVER, SOLENOID & DR SW
01 38	368156	COVER	CVER, LATCH


Base with Toe Kick Panel Assembly



Page/Item	Part No.	Image	Part Description
11 01	485678	INSULATING-/PROTECTION SL	CONDUIT, FLEX 1/2 X 60
11 03	411186	CONNECTION	CONNECTOR, SNAP-ON
11 04	485732	BRACKET	BRACKET, SIDE TO SIDE
11 05	485732	BRACKET	BRACKET, SIDE TO SIDE
11 07	411000	SUPPORT	BUSHING, SNAP 1.0"ID/1.46
11 08	412945	BAG	POLY BAG PACK ANCHOR BRAC
11 09	485762	BRACKET	MTG BRACKET ASSY LT (RK PQ
11 10	485763	BRACKET	MTG BRACKET ASSY RT (RK PQ
11 11	417550	SPRING	Spring, catch
11 12	485753	PANEL	TOE TRIM, SIDE LT BLK (RK
	V01,V02,		
11 12	485757	PANEL	TOE TRIM, SIDE LT S/S (RK
	V03,V04,		
11 12	485755	PANEL	TOE TRIM, SIDE LT WHT (RK
	V05,V06,		
11 13	485752	PANEL	TOE TRIM, SIDE RT BLK (RK
	V01,V02,		
11 15	485756	PANEL	TOE TRIM, SIDE RT S/S (RK
	V03,V04,		
11 15	485754	PANEL	TOE TRIM, SIDE RT WHT (RK
	V05,V06,		
11 18	485747	RAIL	RAIL, BASE FRONT
11 19	411007	STUD	BALL STUD
11 20	368151	PANEL	TOE KICK PANEL ASSY BLK
	V01,V02,		
11 20	485761	PANEL	TOE KICK PANEL ASSY S/S
	V03,V04,		
11 20	142685	PANEL	TOE KICK PANEL ASSY WHT
	V05,V06,		
11 25	411110	SCREW	SCREW 6X1/2 PH TRUSS HD B
11 26	411079	SCREW	SCREW 6-32X1/4 PH RD ZNC
11 27	414752	RIVET	RIVET, POP 1/8 DIA x .250
11 28	411500	SCREW	SCREW 8X1/2 PH PN HD

* Not illustrated


Snorkel Assembly



Page/Item	Part No.	Image	Part Description
13 01	415473	COVER	ENDCAP, SNORKEL T–TOP LT
13 01	415475	COVER	ENDCAP, SNORKEL T–TOP LT
13 03	415472	COVER	ENDCAP, SNORKEL T–TOP RT
13 03	415474	COVER	ENDCAP, SNORKEL T–TOP RT
13 05	487643	COVER	T–TOP, SNORKEL BLK
13 05	487644	COVER	T–TOP, SNORKEL WHT
13 07	485745	FRAME	TRIM, TOP SNORKEL
13 08	414823	SPACER	BEZEL, BLK (CVS)
13 08	414826	BUTTON	BUTTON, UP/DWN SW WHT
13 12	414640	SWITCH	SWITCH, ROTARY 4–POSITION
13 13	189968	SWITCH	SWITCH, UP/DOWN W/TERM
13 14	413765	MOUNTING SET	MOUNT, SWITCH (CVS)
13 15	414821	KNOB	KNOB, BLK (CVS)
13 15	414822	KNOB	KNOB, WHT (CVS)
13 17	143002	AIR CHANNEL	DOWNDRAFT VENTILATION ASS
13 18	486902	FILTER–METALL	FILTER
13 19	368671	FILTER	DOOR, FILTER SNORKEL(RDDS
13 20	368135	HOUSING	HOUSING, SNORKEL
13 21	485577	COVER	SHROUD (RED/RDDS)
13 22	142683	PANEL	PANEL, BACK (RDDS/RED)
13 23	414851	PLUG	PLUG, SNORKEL
13 24	412940	BRACKET	BRACKET, SNORKEL PLUG
13 25	415216	CAPACITOR	CAPACITOR
13 26	487566	MOTOR	MOTOR, SNORKEL UP/DWN
13 27	486304	SWITCH	SWITCH, SNORKEL UPR LIMIT
13 28	414538	SWITCH	SWITCH, SNORKEL LOWER

* Not illustrated


Storage Drawer and Compartment



Page/Item	Part No.	Image	Part Description
15 01	487645	FRAME	TRIM, VENT FORWARD BLK
15 01	487646	FRAME	TRIM, VENT FORWARD WHT
15 03	487634	FRAME-DECOR	TRIM, BACKSPLASH FRONT BL
15 05	415462	COVER	ENDCAP, BACKSPLASH RT BLK
15 05	415465	COVER	ENDCAP, BACKSPLASH LT WHT
15 08	415463	COVER	ENDCAP, BACKSPLASH LT BLK
15 08	415464	COVER	ENDCAP, BACKSPLASH RT WHT
15 10	484738	GLASS DISH	GLASS, BACKSPLASH PNL BLK
15 10	484739	GLASS DISH	GLASS, BACKSPLASH PNL WHT
15 11	485701	STRIP	EXTRUSION, SILICONE 2.5FT
15 13	143245	COVER	COVER, BACKSPLASH
15 14	485726	PANEL	PANEL, BACKSPLASH
15 15	485732	BRACKET	BRACKET, SIDE TO SIDE
15 16	415760	PUSH BUTTON CAP	PUSH MECHANISM (DRAWER)
15 17	486749	INSTALLATION SET	KIT-BASE RAIL 30"RANGE
15 18	369160	DRAWER	DRAWER SLIDE SET (FIXED&M
15 19	142664	DRAWER	DRAWER BODY P-PTD BLK 30"
15 20	238812	DRAWER	DRAWER ASSY, BLK 30"RANGE
15 20	238814	DRAWER	DRAWER ASSY, S/S 30"RANGE
15 20	238813	DRAWER	DRAWER ASSY, WHT 30"RANGE
15 23	142463	GLASS DISH	GLASS, DRAWER BLK
15 23	142464	GLASS DISH	GLASS, DRAWER WHT
15 25	412926	BRACKET	BRACKET, GLASS RETAINER B
15 25	412927	BRACKET	BRACKET, GLASS RETAINER W

* Not illustrated


Base Assembly



Page/Item	Part No.	Image	Part Description
17 02	142684	BASE	BASE W/A (RDDS/RED)
17 03	368141	PANEL	PARTITION, HOUSING (TERM
17 04	485738	CHASSIS	PLENUM, BTM W/A (RDDS/RED
17 05	415394	FOOT	FOOT, LEVELING
17 06	485743	COVER	COVER, FRONT (PLENUM)
17 07	189034	REGULATOR-PRESSURE	REGULATOR, 5" W.C.
17 08	189920	RELAY	RELAY, DBL LINE BREAK
17 09	143089	MOTOR	MOTOR VTN30R
17 10	414730	DAMPER	VIBRATION MOUNT
17 11	414747	BRACKET	BRACKET, MOTOR MTG (VTN30
17 12	414787	NUT	LOCKNUT,#31WLF1420 WHIZ
17 13	188969	NUT	NUT, HEX KEP 1/4-20
17 14	486903	WHEEL	WHEEL, BLOWER
17 15	486503	HOUSING	HOUSING, BLOWER W/A VTN30
17 16	415216	CAPACITOR	CAPACITOR
17 17	414724	SEAL-LID	BOOT, CAPACITOR
17 18	487069	COVER	COVER, EXHAUST VTN30RQ
17 19	413761	INSTALLATION SET	MTG HARDWARE KIT VTN30RQ
17 20	487070	BRACKET	BRACKET, BLOWER (VTN30RQ)
* 40 01	SH-30/0066E		CIRCUIT DIAGRAM
* 40 02	SH-30/0065E		CIRCUIT DIAGRAM
* 40 03	SH-30/0065E		CIRCUIT DIAGRAM
* 50 01	RH30023E	REPAIR INSTRUCTION CGB36R	

* Not illustrated


Maintop Component



Page/Item	Part No.	Image	Part Description
03 01	238680	HOB TOP	MAINTOP CERAN ASY RED30VQ
03 01	V01,V02, 238682	HOB TOP	MAINTOP CERAN ASY RED30VR
03 01	V03,V04, 238681	HOB TOP	MAINTOP CERAN ASY RED30VQ
03 07	V05,V06, 486681	HEATER-ELEMENT	ELEMENT, RADIANT (LF)
03 08	486880	HEATER-ELEMENT	ELEMENT, RADIANT 210/120 (LR)
03 09	486879	HEATER-ELEMENT	ELEMENT, RADIANT 160 1500 (RR)
03 10	486882	HEATER-ELEMENT	ELEMENT, RADIANT 230/140 (RF)
03 11	411224	LAMP	LIGHT, HOT INDICATOR
03 12	487572	BRACKET	BRACKET, HOT INDICATOR LI
03 13	485728	BRACKET	BRACKET R/A, SMALL BURNER
03 14	485727	BRACKET	BRACKET R/A, LARGE BURNER
03 15	368121	PLATE	SHIELD, HEAT CERAN

* Not illustrated


RED30V drop in



Page/Item	Part No.	Image	Part Description
05 01	485764	FRAME	TRIM, SIDE BLK (RDDS/RED)
05 01	V01,V02, 368152	FRAME	TRIM, SIDE S/S (RDDS/RED)
05 01	V03,V04, 485765	FRAME	TRIM, SIDE WHT (RDDS/RED)
05 04	V05,V06, 412946	COVER	COVER, WIRE SIDE
05 05	485705	DUCT	DUCT, SIDE
05 06	414633	FUSE-THERMAL	HTC M2
05 07	415421	SWITCH	SWITCH, OVN LITE
05 08	368159	COVER	COVER, SIDE
05 09	411161	TERMINAL	BLOCK, TERMINAL
05 10	487674	LOCK-MECHANICAL	LATCH ASSY
05 11	485769	AIR DUCT	VENT ASSY (RDDS30V/RED30V
05 12	412944	FRAME	TRIM, RUBBER 7"
05 13	412951	BRACKET	BRACKET, REAR SUPPORT
05 14	414514	LAMP	OVN LAMP RCEP & LENS ASSY
05 15	485690	BRACKET	BRACKET, CONVECTION MOTOR
05 17	368153	DUCT	DUCT, CV AIR
05 18	368161	PANEL	PANEL, BACK (DROP-IN)
05 19	142684	BASE	BASE W/A (RDDS/RED)
05 20	415394	FOOT	FOOT, LEVELING
05 21	414851	PLUG	PLUG, SNORKEL
05 22	412940	BRACKET	BRACKET, SNORKEL PLUG
05 23	368430	DUCT	DUCT, COVER (DROP-IN)
05 24	368160	DUCT	DUCT, CV INTAKE (DROP-IN)
05 25	142688	HOUSING	HOUSING, SNORKEL

* Not illustrated


Main Oven Liner and Module



Page/Item	Part No.	Image	Part Description
07 01	485690	BRACKET	BRACKET, CONVECTION MOTOR
07 02	487099	MOTOR	MOTOR, CONVECTION
07 03	486916	MOTOR	BLADE, MOTOR
07 04	142602	PANEL–SIDE	OVEN BACK MTG 30"OVN
07 05	368109	COVER	COVER, INSULATION 30"RNG
07 06	485770	PLATE	PLATE, HEAT BARRIER DI/FS
07 07	411220	catalyzer	CATALYST
07 08	414191	LAMP	OVEN LAMP W/WIRE KIT
07 09	414152	TEMPERATURE SENSOR	THERMAL SENSOR KIT
07 10	485563	PLATE	PLATE, COVER REAR/SHIELD
07 11	484639	INSULATING PART	INSULATION, CONVECTION MT
07 12	238652	OVEN	CAN, OVN 30" W/A PORC
07 13	485564	VALVE–MAGNET	PAN, REAR CONVECTION
07 14	486202	FAN BLADE	BLADE, CONVECTION RH R/A
07 15	485565	COVER	COVER, CONVECT FAN FRONT
07 16	367555	INSULATING PART	INSULATION, 2" OVN WRAP 1
07 17	485717	DEFLECTOR	DEFLECTOR, HEAT–BROIL
07 18	367645	HEATER–ELEMENT	ELEMENT, OVN BROIL
07 19	238661	MODULE–OPERATING	OVEN MODULE BODY 30"(CT/R
07 20	484627	HOTPLATE	GRIDDLE, BROIL
07 21	484628	VALVE–MAGNET	PAN, BROIL
07 22	414510	HOLDER	SUPPORT, HINGE COUNTER
07 23	368822	SHELF	RACK, OVEN PLATED GE
07 24	367646	HEATER–ELEMENT	ELEMENT, BAKE
07 25	368100	FRAME	FRAME, FRONT TOP RNQ
07 26	415421	SWITCH	SWITCH, OVN LITE
07 27	485696	FRAME	FRAME, FRONT BTM

* Not illustrated

Main Oven Door Assembly



Page/Item	Part No.	Image	Part Description
09 01	238676	DOOR	DOOR ASSY BLK 30" RNG-Q
09 01	V01,V02, 142669	DOOR	DOOR ASSY S/S 30" RNG-Q
09 01	V03,V04, 142668	DOOR	DOOR ASSY WHT 30" RNG-Q
09 04	V05,V06, 484640	INSULATING PART	INSULATION, DOOR SIDE
09 05	367561	INSULATING PART	INSULATION, DOOR BTM
09 06	367560	INSULATING PART	INSULATION, DOOR TOP
09 07	414541	SLEEVE	GASKET, DOOR 65"
09 08	486917	HINGE	HINGE, DOOR
09 09	413386	CLIP	CLIP, WINDOW PACK
09 10	412883	INSTALLATION SET	KIT-GASKET 36INCHES
09 11	369151	SPACER	SPACER, INNER WINDOW/FRAM
09 12	486968	GLASS PANEL	GLASS, INNER DBL COAT 18x
09 13	368109	COVER	COVER, INSULATION 30" RNG
09 14	484796	BRACKET	BRKT, DOOR BTM
09 15	485697	AIR CHANNEL	BAFFLE, AIR
09 16	412936	DOOR	DOOR GLS SUPPORT TOP W/TA
09 17	485718	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 17	V01,V02, 485720	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 17	V03,V04, 485719	SUPPORT	SUPPORT, DOOR GLS SIDE LT
09 20	V05,V06, 485721	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 20	V01,V02, 485723	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 20	V03,V04, 485722	SUPPORT	SUPPORT, DOOR GLS SIDE RT
09 23	V05,V06, 412929	ADHESIVE TAPE	TAPE,FOAM .125thkx.500wdx
09 24	143004	INSTALLATION SET	KIT-DOOR GLASS 30" RANGE B
09 24	V01,V02,V03,V04, 143003	INSTALLATION SET	KIT-DOOR GLASS 30" RANGE W
09 26	V05,V06, 415366	SPACER	SPACER, HANDLE
09 27	412926	BRACKET	BRACKET, GLASS RETAINER B
09 27	V01,V02, 412680	HANDLE	HANDLE END LEFT
09 27	V03,V04, 412927	BRACKET	BRACKET, GLASS RETAINER W
09 30	V05,V06, 487529	HOSE-FILL	FILL TUBE, CHAMFERED
09 30	V01,V02,V03,V04, 487593	HANDLE	HANDLE, OVEN WHT
09 50	V05,V06, 412883	INSTALLATION SET	KIT-GASKET 36INCHES