



Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		Gebrauchsanweisung	instruction manual mode d'emploi
	53 0683 53 0868	V01 V02	
	53 5403	Service Manual	service manual brochure service
	75 7002 75 8041	Fernbedienung V01 V02	remote control telecommande
	75 7246 75 7247 75 7248 75 7249	Verbindungskabel RV □ RC (3 Pin) Verbindungskabel RV □ RA (7 Pin) Verbindungskabel RV □ RH (9 Pin) Verbindungskabel RV □ RH (11 Pin)	connecting cable cable de jonction
	75 2521	Chinchkabel	chinch cable cable de chinch
	73 8808	Metallbrücke	jump plug pont
	75 6977	Lautsprecheranschlußplatte	speaker terminal jack haut parleur
	75 6980	AC– Buchse	AC–outlet douille

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
D103	73 8804	MTZJ3.9B 3,9V 0,5W	
D111	73 8803	MTZJ18B 18V 0,5W	
D125	73 8805	BPC502 5A 100V	
D501	73 8818	LED SLB15MG3	
D601	73 8817	LED SLR54VC5	
D701	73 8804	MTZJ3.9B 3,9V 0,5W	
D703	73 8815	LED SLB15VR3	
D801	73 8816	LED SLR34MC3	
D802	73 8816	LED SLR34MC3	
D803	73 8816	LED SLR34MC3	
D804	73 8816	LED SLR34MC3	
D805	73 8816	LED SLR34MC3	
D806	73 8816	LED SLR34MC3	
	70 6829	1N4148	
	70 9579	1N4002	
			
IC101	72 1972	NJM4558D	
IC102	73 3245	LC7818	
IC103	73 3337	NJM4560D	
IC104	73 3337	NJM4560D	
IC105	73 8793	STK4192	
IC106	73 5617	MC78M15C	
IC107	73 5618	MC79M15C	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC108	73 8795	GD4027UB	
IC109	73 5530	TC9134P	
IC110	73 8794	GD4069UB	
IC401	73 6313	MC78L05AC	
IC701	73 8813	BA6208	
IC901	73 5556	TC9132P	
			
Q1	73 8797	TC1815Y	
Q2	73 8797	TC1815Y	
Q3	73 8797	TC1815Y	
Q4	73 8797	TC1815Y	
Q5	73 8802	DTC114TS	
Q6	73 8798	TA1015Y	
Q7	73 8802	DTC114TS	
Q8	73 8800	DTA114YS	
Q9	73 8801	DTC114YS	
Q10	73 8800	DTA114YS	
Q11	73 8799	TA970GR	
Q12	73 8799	TA970GR	
Q13	73 8800	DTA114YS	
Q14	73 8798	TA1015Y	
Q15	73 8796	TC2240BL	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
Q16	73 8796	TC2240BL	
Q17	73 8797	TC1815Y	
Q18	73 8797	TC1815Y	
Q19	73 8797	TC1815Y	
Q20	73 8797	TC1815Y	
Q21	73 8798	TA1015Y	
Q22	73 8797	TC1815Y	
Q23	73 8797	TC1815Y	
Q24	73 8797	TC1815Y	
Q25	73 8797	TC1815Y	
Q26	73 8797	TC1815Y	
Q27	73 8797	TC1815Y	
Q28	73 8797	TC1815Y	
Q29	73 8798	TA1015Y	
Q401	73 8797	TC1815Y	
Q405	73 8797	TC1815Y	
			
C102	73 8807	C–Netzwerk	C–network
C224	75 6974	6800 µF	
C225	75 6974	6800 µF	
CN101	73 8807	C–Netzwerk	C–network

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
PL1 PL2	73 8819	 Anzeigenlampe	pilot lamp lampe indicateur
	73 8819	Anzeigenlampe	
S501	73 8814	 IR–Empfänger	IR–receiver plaque reception
X101	73 8809		relay relais
	75 6973 75 6978	Relais Relais	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
SW1	73 8821	Netzschalter	power switch
SW2	73 8823	Loudness	X-Bas E.Q.
SW3	73 8822	Lautsprecher A/B	speaker A/B
SW5	73 8824	Tippschalter/Phono/Aux/tape 1/tape 2	tact switch
SW6	73 8824		
SW7	73 8824		
SW8	73 8824		
SW9	73 8824		
SW10	73 8824		
			
	75 6962	Netztrafo	power
	75 6979	Stand by	stand by
			
VR101	73 8806	100 K	
VR102	73 8806	100 K	
VR103	73 8849	250 K	
VR701	73 8820	100 K	
VR701	75 7933	100 K (mit Motor)	

