







Mat. – Nr. – Konstante
3740
Gebrauchsanweisung
58 0487

- 1) 23 6654
- 2) 35 2493
- 3) 16 8053
- 4) 18 3902
- 5) 26 7357
- 6) 26 7359
- 7) 26 7356
- 8) 17 3897
- 9) 17 3898
- 10) 17 3896
- 11) 18 3455
- 12) 18 7489
- 13) 18 6972




Mat. – Nr. – Konstante
3740


- 1) 18 4060
- 2) 18 4400
- 3) 18 4058



Mat. – Nr. – Konstante
3740
1) 35 3489



Mat. – Nr. – Konstante
3740



Mat. – Nr. – Konstante
3740

- 1) 16 9339
- 2) 17 3894
- 3) 17 3895
- 4) 26 7950
- 5) 26 7951
- 6) 26 7949
- 7) 35 7810
- 8) 35 7811
- 9) 35 7809
- 10) 35 7808
- 11) 17 4634

Duesensatz Für:
EG H/E G20 20mbar
17 4049

FG G30/31 30mbar
17 4048

EG H/E G20 20mbar
(inkl.Bypassduesen)
41 7597

FG G30/31 30mbar
(inkl.Bypassdusen)
41 7837