







Pos. Item Pos.	Ident-Nr. Idenr-No N° d'ident	Bezeichnung	Designation Désignation
			
Q101	70 6243	BF195	
Q102	70 6245	BF241	
Q201	70 7233	BC238B	
Q401	70 7233	BC238B	
Q403	70 7233	BC238B	
Q404	70 7233	BC238B	
Q406	70 7233	BC238B	
Q501	70 7233	BC238B	
Q502	70 7233	BC238B	
Q503	70 7233	BC238B	
Q504	70 7233	BC328B	
Q505	70 7233	BC238B	
Q551	70 7233	BC238B	
Q601	70 7233	BC238B	
Q603	70 7233	BC238B	
Q604	70 7233	BC238B	
Q701	70 7233	BC238B	
Q702	70 7233	BC238B	
Q751	71 1900	BD135/16	
			
D101	73 9013	BAP794	
D102	72 3221	BB105G	
D103	73 9014	811	
D104	73 9010	BAYP94	
D302	73 9010	BAYP94	
D303	73 9010	BAYP94	
D304	73 9010	BAYP94	
D401	73 9010	BAYP94	
D402	73 9010	BAYP94	
D451	73 9010	BAYP94	
D501	73 9010	BAYP94	
D502	73 9010	BAYP94	
D751	73 9009	BZP683C6V8	
D801	73 9011	BYP401/50	
D802	73 9011	BYP401/50	
D803	73 9011	BYP401/50	
D804	73 9011	BYP401/50	

Pos. Item Pos.	Ident-Nr. Idenr-No N° d'ident	Bezeichnung	Designation Désignation
D301	73 9012	 CQP411	
IC201	73 9035	 TA8108AP	
IC301	73 3404	TA7343AP	
IC401	73 1470	TC4016BP	
IC501	73 3855	TA7668BP	
IC601	73 9008	A2000V	
VR601	73 9006	 Klang	Tone, regulateur de tonalité
VR602	73 9006	Klang	Tone, regulateur de tonalité
VR603	73 9005	Lautstärke	Volume
VR604	73 9005	Lautstärke	Volume
VR605	73 9007	Balance	
S1	73 9004	 A/W	R/P
S2	73 9002	AM/FM/Tape, Funktion	
S3	73 9003	Dubbing-Beat	
S4	73 9002	Wellenbereiche	Ranges, gamme d'ondes
	43 0176	Austauschgerät	Exchange apparatus Appareil d'échange
	53 0712	Gebrauchsanweisung	Operating instructions Instructions de service
	53 5399	Service Druckschrift	Service booklet Brochure service

