








Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
52 8124
(D,GB,F,I,NL)

Montageanleitung
52 2772
(D,GB,F,I,NL,DK,N,SF,
SE,TR)

Beistellsatz
26 5629

Promotionartikel
Kühltasche
36 2403

Mat. – Nr. – Konstante
3740



Pos.	V01		
	Danfoss		
	NLE11 KK2		
1	14 2163		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7			
8	20 9294		
9	050166		
10			
11	01 9017		
12	01 9016		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		NLE11 KK2		
Förderleistung/Delivery/Débit		2007		
Anlaufstrom/Starting current/Cour de démarrage		A		
Widerstand/Resistance/Résistance Ha/main/prin		Ω		
Hi/aux		Ω		
Temp.–Regler/Thermostat				
Typ/Type				
Regelstellung/Position				
Schaltwerte/Switching values		"warm"		
Valeurs de commutation		"kalt"		
		"alarm"		
Füllmenge/Fill.quantity/Charge		R600a		
Anschlußwert/Conn.load/Puiss. connectée		W		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
NTC–Fühler / Sensor		°C		kΩ
		+10		9,95 ±0,18
		+5		12,70 ±0,18
		0		16,33 ±0,16
		–18		43,31 ±1,10
		–22		54,66 ±1,59
		–26		69,42 ±2,29
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		