


**BOSCH**

WFK6000-WFK6000/06-D1
 WFK6000-WFK6000FG/06-FG1
 WFK6000-WFK6000SI/06-SI1

WASCHGERÄTE
 Waschvollautomaten

Mat. - Nr. - Konstante
 3740



Aufstellanweisungen:

51 3556
 (D,I,S,N,SF)
 51 3557
 (S,DK)
 51 3558
 (NL,F,E,GB)

- 1) 27 7718
 Blende kompl.
- 2) 08 8738
 (D,I)
 08 8734
 (NL,F)
 08 8735
 (S,DK)
 08 8736
 (E,GB)
 08 8737
 (SF,N)

Gebrauchsanweisungen:


51 3566
 (D,I,S,N,SF)
 51 3567
 (S,DK)
 51 3568
 (NL,F,E,GB)
 Programmtabellen:
 51 3552
 (D)
 51 3553
 (I,S,N,SF)
 51 3554
 (S,DK)
 51 3555
 (NL,F,E,GB)

**BOSCH**

WFK6000-WFK6000/06-D1
WFK6000-WFK6000FG/06-FG1
WFK6000-WFK6000SI/06-SI1

WASCHGERÄTE
Waschvollautomaten

Mat. - Nr. - Konstante
3740




**BOSCH**

WFK6000-WFK6000/06-D1
 WFK6000-WFK6000FG/06-FG1
 WFK6000-WFK6000SI/06-SI1

WASCHGERÄTE
 Waschvollautomaten

Mat. - Nr. - Konstante
 3740

1) 27 1716
 15 5272
 Triac-Motorleistung



**BOSCH**

WFK6000-WFK6000/06-D1
WFK6000-WFK6000FG/06-FG1
WFK6000-WFK6000SI/06-SI1

WASCHGERÄTE
Waschvollautomaten

Ident.-Nr. - Mat. - Nr. - Konstante
37. 3740

