




Gebrauchsanleitung


52 2693


Montage-/Aufstellanl.

58 8057

Befestigungssatz

49 1368





	V01		
Pos.	Aspera BPK 1084Y		
1	56		
2			
3	57		
4			
5	59		
6	60		
7	61		
8	62		
9	63		
10			
11	65		
12	66		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Aspera			
Typ/Type		BPK 1084Y			
Förderleistung/Delivery/Débit		l/h	1201		
Anlaufstrom/Starting current/Cour de démarrage		A	3,6		
Widerstand/Resistance/Résistance		Ha/main/prin	W	29,6	
		Hi/aux	W	39,1	
Temp.-Regler/Thermostat		KER			
Typ/Type		RCO			
Regelstellung/Position		kalt	warm		
Schaltwerte/Switching values		ein"	+5,2		
		aus"	+5,2		
Valeurs de commutation		"alarm"	-32,0	-15,0	
Füllmenge/Fill.quantity/Charge		R600a	*		
Anschlußwert/Conn.load/Puiss. connectée		W	79		
Heizung/Heater/Chauffage					
Widerstand/Resistance/Résistance		W			
Leistung/Power/Puissance		W			
Ventilator/Blower/Ventilateur					
Widerstand/Resistance/Résistance		W			
Temp.-Regler/Thermostat					
Magnetventil/Magnetic valve/Electrovanne					
Widerstand/Resistance/Résistance		W			
Spannung/Voltage/Tension		V			

* siehe Typenschild