



Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
		ELEKTRISCHE TEILE	ELECTRICAL PARTS PIECES ELECTRIQUE
			
IC1	73 2591	TA 7358AP	
IC2	73 6721	TA8132N	
IC3	73 6722	BA3516	
IC4	73 6723	TC9308AF005	
IC5	73 6724	TD6134A	
IC6	73 2402	LA5523	
			
Q1/Q4/Q6	73 6725	2SA1317T	
Q5/Q7/Q8	72 9907	2SC3330U	
Q11/Q12/ Q13			
Q9	73 6727	KTK117	
Q14	72 7063	2SC2999D	
			
D3/D5	73 6187	1SV101(FM)	
D7/D8	73 6188	1SV149B(AM)	
D9/10/ D12	73 3410	1SS133TP	
D11	73 6727	1N60	
			
X3	73 6766		
			
X1	73 6767		
X2	73 6768		
CF1	73 6281	FM-ZF	
CF2	73 6282	AM-ZF	
	73 8338	Ohrhörer	earphone/ecouteur oreilles



Laufwerk kpl. 78 2331
 Mechanism kpl.



Pos. Item Pos.	Ident-Nr. Ident-No N° d'ident	Bezeichnung	Designation Désignation
	43 0146	Austauschgerät	Exchange apparatus Appareil d'échange
	53 0602	Gebrauchsanweisung	Operating instructions Instructions de service
	53 5328	Service-Druckschrift	Service booklet Brochure service