


**BOSCH**

WFK4410-WFK4410FG/01-FG1
 WFK4410-WFK4410SI/01-SI1
 WFK4410-WFK4410FG/02-FG2
 WFK4410-WFK4410SI/02-SI2

WASCHGERÄTE
 Waschvollautomaten



Ident - Nummern - Konstante
 3740

- 1) 08 6336
 (D)
 08 6337
 (NL)
 08 6338
 (N)
 08 6339
 (SF)
 08 6340
 (S)
 08 6341
 (E)
 08 6342
 (F)
 08 6343
 (DK)
 08 6344
 (I)
 08 6686
 (TR,YU,E,GB)
 08 6690
 (GB)

Gebrauchsanweisungen:


- 51 3566
 (D,I,S,N,SF)
 51 3568
 (NL,F,E,GB)

Programmtabellen:

- 51 3552
 (D)
 51 3553
 (I,S,N,SF)
 51 3555
 (NL,F,E,GB)

Aufstellanweisungen:


- 51 3556
 (D,I,S,N,SF)
 51 3558
 (NL,F,E,GB)



**BOSCH**

WFK4410-WFK4410FG/01-FG1
 WFK4410-WFK4410SI/01-SI1
 WFK4410-WFK4410FG/02-FG2
 WFK4410-WFK4410SI/02-SI2

WASCHGERÄTE
 Waschvollautomaten



Ident – Nummern – Konstante
 3740

- 1) 03 0055
LINKS
03 0054
RECHTS
- 2) 03 0052
RECHTS
03 0051
LINKS


**BOSCH**

WFK4410-WFK4410FG/01-FG1
 WFK4410-WFK4410SI/01-SI1
 WFK4410-WFK4410FG/02-FG2
 WFK4410-WFK4410SI/02-SI2

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740

1) 27 0442
 15 5272
 Triac-Motorleistung



**BOSCH**

WFK4410-WFK4410FG/01-FG1
WFK4410-WFK4410SI/01-SI1
WFK4410-WFK4410FG/02-FG2
WFK4410-WFK4410SI/02-SI2

WASCHGERÄTE
Waschvollautomaten

Ident - Nummern - Konstante
3740

