


Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
11914	099357	Waennchen	Tub
12093	293502	Deckel	Cover
12130	321869	Buchse	Bushing
12131	321868	Knopffeder	Spring
12132	321950	Scheibe	Washer
12396	322637	Federhalterung	Spring support
12397	322899	Ring	Ring
12398	320127	Ring	Ring
12399	320113	Feder	Ressort
12439	320258	Ring	Ring
16222	158500	Drucktaste - 160	Push-button - 160
	158520	Drucktaste - 120	Push-button - 120
	158106	Drucktaste - 110	Push-button - 110
17944	211917	Waschmittelbehaelter	Bin for washing powder
17945	294151	Einlaufschlauch	Opening hose
19425	158502	Schraubenschutz	Screw protection
19429	158503	Schraubenschutz	Screw protection
19435	099838	Programmschalter	Program switch
	099958	Programmschalter	Program switch
19442	158505	Drucktaste	Push button
19443	099843	Druckwaechter	Pressure guide
19444	099844	Drehwechsler	Change over
19446	294156	Schalterblende	Switch board panel - 160
	294164	Schalterblende - 120	Switch board panel - 120
	294168	Schalterblende - 110	Switch board panel - 110
19447	233455	Blendenleiste oben	Panel , top
19448	099898	Drucktastendeckel - 160	Cover, push-button -160
	158556	Drucktastendeckel - 120	Cover, push-button -120
	099899	Drucktastendeckel - 110	Cover, push-button -110
19449	158506	Licht EIN/AUS	Lamp ON/OFF
19450	158555	Programmschalterknebel-160	Knob. program switch
	158557	Programmschalterknebel -120	Knob, program switch
	158558	Programmschalterknebel-110	Knob, program switch
19451	158507	Temp.-reglerknebel-160	Knob, thermostat - 160
	158521	Temp.-reglerknebel-120	Knob, thermostat - 160
	158525	Temp.-reglerknebel -110	Knob, thermostat - 110
19452	158508	Knebel - 160	Knob - 160
	320438	Knebel - 120	Knob - 120
	158526	Knebel - 110	Knob - 110
19453	294158	Waschmitteltuerchen-160	Wash powder door - 160
	099854	Waschmitteltuerchen - 120	Wash powder door - 120
	099897	Waschmitteltuerchen - 110	Wash powder door - 110
19455	158509	Feder	Spring
19456	099845	Waschmittellinnentuere	Wash powder inner door
19457	099846	Blendenleiste unten	Panel, bottom

GAGGENAU

ERSATZTEILLISTE SPARE PARTS LIST EW 136-160/120/110



Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
11887	321947	Stift	Pin
11888	321875	Scheibe	Disc
11894	158098	Feder	Spring
11907	293499	Sockel schwarz	Base, black
11909	321761	Schlauchanschluss	Hose connecting part
11912	293500	Waschmittelbehaelter	Detergent container
11913	099356	Deckel	Cover
11916	099358	Ablaufpumpe	Drain pump
12086	320881	Stift	Pin
12098	233421	Bullauge -160	Porthole -160
	294163	Bullauge -120	Porthole -120
	141459	Bullauge -110	Porthole -110
12100	099363	Elektroventil	el.valve
12116	321940	Scheibe	Washer
12121	293508	Schlauch	Hose
12413	099823	Fuehrung	Guide
12987	158486	Stift	Pin
12990	158488	Buegel	Bracket
12991	099819	Bullaugenhandgriff-160	Porthole handle - 160
	099853	Bullaugenhandgriff-120	Porthole handle - 120
	099858	Bullaugenhandgriff-110	Porthole handle - 110
12992	158489	Haken	Hook
13899	099826	Deckel	Cover
14999	099831	Scharnierhalter	Support, hinge
15719	294150	Bullaugenrahmen	Frame, porthole
15958	158246	Schlauch	Hose
17855	321775	Halter	Support
17860	158501	Feder	Spring
17940	099834	Schlauch	Hose
17942	099835	Schlauchhalter	Support, hose
17943	158524	Carter hinten,	Carter, backside
18854	294152	Bottichschlauch	tub hose
19424	211918	Gehaeuse	Housing
	294260	Gehaeuse	Housing
19426	099837	Schlauchendstueck	Hose end part
19437	099839	Druckwaechter	Pressure guide
19438	158504	Zetteltraeger	Support
19439	099840	Schutz	Protection
19440	099841	Geschwindigkeitseinstell.	Speed controller
	099959	Geschwindigkeitsregler	Speed controller


Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
19458	099847	Einstelleiste - 160	Adjustable panel - 160
19458	099847	Einstelleiste - 160	Adjustable panel - 160
	099855	Einstelleiste - 120	Adjustable panel - 120
	099859	Einstelleiste - 110	Adjustable panel - 110
19459	099848	Einstelleiste - 160	Adjustable panel - 160
	099856	Einstelleiste - 120	Adjustable panel - 120
	099860	Einstelleiste - 110	Adjustable panel - 110
19460	294159	Blendenleiste unten - 160	Panel bottom - 160
	294165	Blendenleiste unten - 120	Panel bottom - 120
	294169	Blendenleiste unten - 110	Panel bottom - 110
19461	158510	Einstellstift	Adjustable pin
19452	158511	Mutter	Nut
19463	158512	Schraube	screw
19464	158513	Signallampe	Signal light
19465	158514	Halter	Support
19971	158516	Scharnierstift	Hinge pin

GAGGENAUERSATZTEILLISTE
SPARE PARTS LIST

EW 136-160/-120/-110



Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
18	099397	Stossdaempfer	Shock absorber
50	099133	Dichtungsspannring	Clamp for gasket
973	157856	Lager	Bearing block
974	157857	Lager	Bearing block
1397	157630	Schlauchklemme	Clamp
1411	293310	Schlauchklemme	Clamp
1990	323210	Gummipuffer	Stopper
1991	320843	Gummipuffer	Stopper
2148	320615	Dichtung	Gasket
2186	293313	Dichtung	Gasket
2187	157863	Dichtung	Gasket
2202	157864	Dichtung	Gasket
2233	323197	Dichtung	Gasket
2239	099144	Dichtung	Gasket
4305	321958	Scheibe	Washer
4312	321939	Scheibe	Washer
4590	322679	Buegel	Bracket
4723	211712	Korbtraeger	Basket support
7720	099820	Riemen	Belt
7728	099896	Scheibe	Shield
8849	158554	Nabe	Hub
8942	099821	Abstandsstueck	Distance piece
9152	321835	Schlauchklemme	Clamp
9509	158553	Schraube f. Motor	Screw f. motor
10161	158483	Mutter	Nut
11855	141444	Gegengewicht vorne	Set weight, front
11879	320900	Einlaufschlauch	Hose, inlet
11881	158095	Ablauffilter	Filter
11908	158099	Ring	Ring
11911	320905	Dichtung	Gasket
12084	099361	Halter	Support
12085	322672	Filtertuer	Filter door
12086	320881	Stift	Pin
12087	322290	Feder	Spring
12122	322757	Schlauchklemme	Clamp
12820	293497	Ablaufschlauch	Hose, outlet
12988	158487	Anschluss	Connecting part
12993	158490	Feder	Spring
12994	158491	Klemme	Clamp
13118	158492	Scheibe	Disc
14226	158493	Mutter	Nut
14227	158494	Mutter	Nut
14228	158495	Scheibe	Disc
14229	158496	Schraube	Screw
14230	099829	Gegengewichtsschraube	Screw, set weight

Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
14231	099830	Gegengewichtsschraube	Screw, set weight
15006	158497	Ring	Ring
16226	141456	Gegengewicht	Set weight
19430	211926	Waschbottich	Wash tub
19432	211927	Trommel	Drum
19433	141457	Motor	Motor
19434	294154	Bottichdeckel	Cover
19441	099842	Druckwaechter,vorwaschen	Thermostat
19445	294155	Heizung	Heating element
19556	099849	Einlaufsyphen	Pipe

Stueckliste E620009

EW136110 EW136120 EW136160

Pos.	Mat-Nr.	Bezeichnung	Description
403	099005	Schellenbuegel	Fixing part
413	099134	Speisungsbuegel	Power cord
1032	293342	Bullaugenglas	Porthole glass
1395	320482	Schlauchklemme	Clamp
1623	098904	Filter	Filter
1654	157862	Kabelbefestigung	Fixing part
2150	098906	Dichtung	Gasket
3050	323237	Feder	Spring
3064	157867	Feder	Spring
3631	157869	Fuss	Feed
3983	320957	Schutz	Protecting part
4000	099004	Schutz	Protecting part
4441	157871	Verschluss	Locking mechanism
	099960	Verschluss	Locking mechanism
4688	321954	Niveauschaltertraeger	Support
5202	293318	Schlauch	Hose
6984	157877	Federschutz	Spring protection
7209	321847	Klemmenblock	Terminal connector
8923	157880	Kabelbefestigung	Fixing part
9152	321835	Schlauchklemme	Clamp
9170	099822	Schutz	Protection
10359	293343	Ablaufschlauch	Drain hose
10456	158484	Funkentstoerfilter	Filter
	158614	Entstoerfilter	Anti-disturb filter
11850	141443	Gegengewicht	Set weight
11851	321889	Fuehrung rechts	Guide, right side
11852	321836	Fuehrung links	Guide, left side
11859	158093	Scharnier	Hinge
11860	158094	Verschluss	Locking mechanism
11862	321943	Plaettchen	Plate
11863	321819	Haken	Hook
11864	321762	Buegel	Bracket
11865	321809	Haken linksseit.	Hook, left side
11866	321951	Haken rechtsseit.	Hook, right side
11867	321817	Pfropfen	Stopper
11868	321946	Plaettchen	Plate
11871	293495	Schlauch	Hose
11872	321938	Schlauchpfropfen	Hose stopper
11874	293496	Luftfalle	Air trap
11883	099353	Dichtung	Gasket
11884	322285	Buegel	Bracket
11886	099354	Scharnier	Hinge