




Gebrauchsanweisung
52 0073 (de)
V01
52 0745 (de)
V02
52 2002 (de)
V03

Zubehör:

Universalpfanne
HZ 23300

Kombirost
HZ23400


Backblech Alu
HZ 21000


Glasbräter
HZ 9150


Backblech emailliert
HZ 23100

Grillblech
HZ 22500


1) 01 4254







1) 16 7505



1) 16 3067
Set

