





Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
52 2769
(D,GB,F,I,NL)

Montageanleitung
52 2772
(D,GB,F,I,NL,DK,N,SF,
SE,TR)

Beistellsatz
26 5629

Side by Side
Beistellsatz zu KSR/KSK
48 1044

Mat. – Nr. – Konstante
3740



Pos.	Danfoss		
	TLES9K		
1	14 1660		
2			
3	15 1055		
4			
5	15 0760		
6	15 1072		
7			
8	21 4604		
9	050166		
10			
11	01 9017		
12	01 9016		

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		TLES9K		
Förderleistung/Delivery/Débit		l/h	1589	
Anlaufstrom/Starting current/Cour de démarrage		A	8,8	
Widerstand/Resistance/Résistance		Ω	16,5	
Hi/aux		Ω	16,9	
Temp.–Regler/Thermostat				
Typ/Type				
Regelstellung/Position				
Schaltwerte/Switching values		"warm"		
Valeurs de commutation		"kalt"		
		"alarm"		
Füllmenge/Fill.quantity/Charge		R600a	100	
Anschlußwert/Conn.load/Puiss. connectée		W		
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance		Ω		
Leistung/Power/Puissance		W		
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance		Ω		
NTC–Fühler / Sensor		°C	kΩ	°C
		+10	9,95 ± 0,18	–18
		+5	12,70 ± 0,18	–22
		0	16,33 ± 0,16	–26
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance		Ω		
Spannung/Voltage/Tension		V		