


**BOSCH**

BBS 5000 – 0 752 210 147–EXP.1
 BBS 5001 – 0 752 210 172–S1
 BBS 500111 – 0 752 210 202–EXP.2

BBS 500246 – 0 752 210 275–NL1

BODENPFLEGEGERÄTE
 Bodenstaubsauger

Ident – Nummern – Konstante
 3740



Gebrauchsanweisung
 51 2647
 Exp.1,NL1
 (NL)
 51 7809
 S1
 (D,DK,N,SF,S)
 51 3466
 Exp.2
 (D,NL,F,I,GB)

1) 08 4961
 2) 05 4781
 3) 02 0271
 4) 11 4492
 Exp.1,Exp.2
 11 7810
 S1
 11 8595
 NL1

5) 08 0013
 Exp.1
 08 5650
 Exp.2,S1,NL1
 6) 02 9874
 ab FD 6704