







51 1712
Aufstellanweisung
(D, F, I, NL, GB, E)


51 2162
Gebrauchsanweisung
(D, F, I, NL, GB, E)

51 1718
Programmtabelle
(D, F, I, NL, GB, E)

1) 08 1582
bis FD 6701
08 5943
ab FD 6702







- 1) 07 3594
220V
07 3981
240V
- 2) 14 0112*
bis FD 6510
D1
14 0372
ab FD 6511
D1
14 0377
GB1

* 05 0117
bis FD 6409
mitbestellen

