




ELECTRIC PRESSURE COOKER
AEG ELECTROLUX
PNC 900 082 815
MODEL: EPC6000
DATE: 21.7.2008

PARTS LIST - ELECTRIC PRESSURE COOKER

AEG ELECTROLUX

PNC: 900 082 815

MODEL: EPC6000

DATE: 21.7.2008

PAGE 2 OF 5

Item No.	Part No.	DESCRIPTION	Qty / assy
1	14596-000	HANDLE COVER LID	1
2	14595-000	HANDLE LID	1
3	14594-000	PLASTIC COVER LID	1
4	14643-000	LID	1
5	14644-000	SEAL RING, CENTRE PIN	1
6	14645-000	SEAL RING , LID	1
7	14646-000	INNER LID ASSEMBLY	1
8		SCREW	2
9		LOCK WASHER	1
10		INNER LID	1
11		INNER LID HANDLE	1
12	14647-000	PRESSURE LIMIT VALVE ASSEMBLY	1
13		PRESSURE LIMIT VALVE HANDLE	1
14		PRESSURE LIMIT VALVE CORE	1
15		PRESSURE LIMIT VALVE SEAL RING	1
16		PRESSURE LIMIT VALVE PIN	1
17	14648-000	PRESSURE LIMIT VALVE BODY	1
18	14649-000	PRESSURE INDICATOR ASSEMBLY	1
19		PRESSURE INDICATOR	1
20		FLOAT VALVE	1
21	14650-000	SEAL RING, FLOAT VALVE	1
22	14651-000	NUT	1
23	14652-000	NUT	1
24	14653-000	SPRING	1
25	14654-000	LOCK LEVER ASSEMBLY	1
26		LOCK LEVER	1
27		LOCK LEVER BOARD	1
28		LOCKING SPRING	1
29		LOCK LEVER SEAL RING	1
30	14655-000	INNER WIRE	1
31	14656-000	O-RING	1
32	14657-000	ANTI-BLOCK HOLDER	1
33	14658-000	ANTI-BLOCK NUT	1
34	14659-000	ANTI-BLOCK COVER	1
35	14660-000	HOLDING RING	1
36	14661-000	INNER POT	1

PARTS LIST - ELECTRIC PRESSURE COOKER

AEG ELECTROLUX

PNC: 900 082 815

MODEL: EPC6000

DATE: 21.7.2008

PAGE 3 OF 5

Item No.	Part No.	DESCRIPTION	Qty / assy
37	14662-000	HEATING ELEMENT ASSEMBLY	1
38		HEATING ELEMENT	1
39		SENSOR	1
40	14663-000	OUTER POT SUPPORT S/S PIECE	6
41	14664-000	OUTER POT	1
42	14665-000	PRESSURE CUT-OUT BRACKET	1
43	14666-000	OUTER BODY BRACKET	3
44	14597-000	RING TOP	1
45	14598-000	HANDLE SIDE	2
46	14667-000	HANDLE HOLDER	2
47	14668-000	PCB INDICATING BOARD	1
48	14669-000	INDICATOR WINDOW	1
49	14670-000	CONTROL PANEL	1
50	14671-000	BUTTON SPRING	3
51	14672-000	BUTTON - MENU	1
52	14673-000	BUTTON - TIME	1
53	14674-000	BUTTON - START / CANCEL	1
54	14675-000	PRESSURE CUT-OUT	1
55	14676-000	PRESSURE CUT-OUT	1
56	14677-000	FUSE CLAMP	1
57	14678-000	WATER COLLECTOR	1
58	14679-000	OUTER BODY	1
59	14680-000	PCB BRACKET	1
60	14681-000	PCB FRAME, PLASTIC	1
61	14682-000	PCB POWER BOARD	1
62	14683-000	BASE	1
63	14684-000	ANTI- SLIDE FOOT	6
64	14685-000	BOTTOM PLATE	1
65	14686-000	POWER CORD	1
66	14687-000	FUSE ASSEMBLY	1
67	14688-000	POWER CORD SOCKET	1
68	14689-000	FLOAT COVER	1
69	14604-000	RIGHT COVER, LID,	1
70	14605-000	LEFT COVER, LID	1
71	14690-000	TRIVET	1
	14568-000	INSTRUCTION / RECIPE BOOKLET	1