

This diagram illustrates the exploded view of a microwave oven assembly. The components are labeled with numerical identifiers. Key parts include the outer cabinet (0020), the microwave door (1212) with its handle (1213) and latch (1214), the door hinge assembly (6510, 6520), the main body (0010), the turntable (2640) with its support (2641), the magnetron (4900), the waveguide (4810), the cooling fan (4430), and the control panel (0022) with its display (0023) and buttons (0024). The diagram also shows the internal structure, including the waveguide (4852), the turntable support (4200), and the mounting brackets (4040, 4041, 4042, 4043). The exploded view shows the relationship between these components and how they fit together to form the complete microwave oven.