

OUTER FRAME ASSY
NH102049528

Diagram illustrating the assembly of the Outer Frame Assy (NH102049528). The components shown include:

- 170, 172, 365: Cables and connectors.
- 145: A long vertical component, likely a hinge or support.
- 355, 356A: A small assembly component.
- 363: A large vertical component, likely a hinge or support.
- 1: A small component at the top right.
- 7, 40, 41: Components on the right side of the frame.
- 8, 9, 10: Small components near the bottom center.
- 359: A component on the bottom right.
- 457: A component on the bottom right.
- 360: A component on the bottom right.
- 13: A small component at the bottom right.

-13