



Electrolux

SPARE PARTS LIST

Food Preparation

3483

Item	PNC	ELC	Brand	Model	Market
A	900275935	00	Electrolux	EFP9804C	AUW

SAFETY WARNING


Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.

Electrolux SEA Pte.,Ltd. APAC		Publication-No. 150427	Small Appliance Food Preparation Blender
----------------------------------	--	---------------------------	--

Model	PNC
EFP9804C	900275935

Ex. View Drawing Internal Parts and Accessories



PNC	ELC	Brand	Model	Market
900275935	00	Electrolux	EFP9804C	AUW

Parts No.	Supplier Parts No.	Parts Name
42	SPA285010-A00000	Base Coupling ASS (Copper)
43	PLA285015-001B02	Bowl Lock Plate (Copper)
44	PLA284014-001A02	Plastic Collar (Copper)
50	PLA285046-004F02	UI Panel (Copper)
54	SPA285011-A00000	Adjustable Slicing Blade ASS (Copper)
55	SPA285012-A00000	Start Button ASS (Copper)
56	SPA285013-A00000	Pulse Button ASS (Copper)
57	SPA285014-A00000	Power Button ASS (Copper)
58	RUB285007-020ZD0	Buttons Seal
59	PLA285021-002A01	PCB Bracket
62	PCB285230-001E0A	Control PCB Assy (230V)
64	PCB285230-001E0B	Main PCB Assy (230V)
67	SPA285015-000000	Start-up Capacitor
68	SPA285017-A00000	Safety Switch ASS (Copper)
69	DCS285001-B56000	Die_cast Housing (Copper)
75	SPA285022-A00000	Power Cord with Plug (c-SAA)
76	PLA285049-001A02	Cord Wrap Cover (Copper)
77	RUB285011-020GD1	Back Rubber Feet
78	RUB285008-020GD1	Preceding Rubber Feet left
79	RUB285012-020GD1	Preceding Rubber Feet right
82	RUB280016-020BD0	Motor Gasket upper
84	RUB280005-020ZD0	Motor Rubber Washer
87	MOTY128352302NTG	MOTOR
88	RUB285010-020GD0	Motor Cushion
89	RUB285009-020GD0	Motor Gasket Lower
90	SPA285019-000000	Ass. Start-up Relay (230V)

Accessories

Parts No.	Supplier Parts No.	Parts Name
1	SPA285001-A00000	Small Pusher (Copper)
3	SPA285002-A00000	Big Pusher ASS (Copper)
6	SPA285003-A00000	Bowl Lid ASS (Copper)
14	RUB285001-020G01	Bowl Lid Seal (Copper)
21	SPA285004-A00000	Processing Bowl ASS (Copper)
32	SPA285005-A00000	S-Blade ASS (Copper)
33	PLA285045-001A02	Whisk (E-Disc) (Copper)
34	SPA285006-A00000	Spindle ASS (Copper)
35	PLA285024-010A02	Dough-Blade (Copper)
36	SPA285007-A00000	Mini S-Blade ASS (Copper)
37	PLA285002-013B01	Mini Bowl
38	SPA285008-A00000	Julienne Disc ASS (Copper)
39	SPA285009-A00000	Shredding Disc ASS (Copper)
999	SPE285003-000000	Accessories Bag