



Item	PNC	ELC	Brand	Model	Market
A	900275943	00	Electrolux	EMB3005	THE
A	900275945	00	Electrolux	EMB3005	KRH

SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.

Electrolux SEA Pte.,Ltd. APAC		Publication-No. 150203	Small Appliance Food Preparation Sportblender
----------------------------------	--	---------------------------	---



Model

PNC

EMB3005 900275943

EMB3005 900275945

Ex. View Drawing Internal Parts and Accessories



PNC	ELC	Brand	Model	Market
900275943	00	Electrolux	EMB3005	THE
900275945	00	Electrolux	EMB3005	KRH

Pos.	Part Code	Description	900275943	900275945
1	999404561	Lid Assembly	•	•
2	999404571	Bottle	•	•