


**BOSCH**

SOLIDA 10 –BBS1011DF/01–DF1, weiss  
 SOLIDA 10 –BBS1011CH/01–CH1, weiss  
 SOLIDA 10 –BBS1032DF/01–DF2, grau

SOLIDA 10 –BBS1032DF/04–DF3, grau

BODENPFLEGEGERÄTE  
 Bodenstaubsauger

Ident – Nummern – Konstante  
 3740 . . . . .



**Gebrauchsanweisungen:**  
 51 3848  
 DF1,DF2,CH1  
 (D,GB,N,F,I,NL,DK,S,SF,E,P,GR)  
 51 5325  
 DF3  
 (D,GB,N,F,I,NL,DK,S,SF,E,P,GR)

**Zubehör:**  
 Möbelpinsel  
 BBZ21MP,grau




**BOSCH**

SOLIDA 10 –BBS1011DF/01–DF1, weiss  
SOLIDA 10 –BBS1011CH/01–CH1, weiss  
SOLIDA 10 –BBS1032DF/01–DF2, grau

SOLIDA 10 –BBS1032DF/04–DF3, grau

BODENPFLEGEGERÄTE  
Bodenstaubsauger

Ident – Nummern – Konstante  
3740 . . . . .





**BOSCH**

SOLIDA 10 –BBS1011DF/01–DF1, weiss  
SOLIDA 10 –BBS1011CH/01–CH1, weiss  
SOLIDA 10 –BBS1032DF/01–DF2, grau

SOLIDA 10 –BBS1032DF/04–DF3, grau

BODENPFLEGEGERÄTE  
Bodenstaubsauger

Ident – Nummern – Konstante  
3740 . . . . .

