


Ident – Nummern – Konstante
 3740



Gebrauchsanweisungen:
 51 3848
 DF1,DF2,CH1
 (D,GB,N,F,I,NL,DK,S,SF,E,P,GR)
 51 5325
 DF3
 (D,GB,N,F,I,NL,DK,S,SF,E,P,GR)

Zubehör:
 Möbelpinsel
 BBZ21MP,grau




BOSCH

SOLIDA 10 –BBS1011DF/01–DF1, weiss
SOLIDA 10 –BBS1011CH/01–CH1, weiss
SOLIDA 10 –BBS1032DF/01–DF2, grau

SOLIDA 10 –BBS1032DF/04–DF3, grau

BODENPFLEGEGERÄTE
Bodenstaubsauger

Ident – Nummern – Konstante
3740





BOSCH

SOLIDA 10 –BBS1011DF/01–DF1, weiss
SOLIDA 10 –BBS1011CH/01–CH1, weiss
SOLIDA 10 –BBS1032DF/01–DF2, grau

SOLIDA 10 –BBS1032DF/04–DF3, grau

BODENPFLEGEGERÄTE
Bodenstaubsauger

Ident – Nummern – Konstante
3740

