





Gebrauchsanweisung
58 0139
(de,fr)


1) 02 5876

Zubehör:


Grillpfanne u. Bratrost
Z1230X0
Back,- u. Bratrost
Z1430X0
Bratenblech
Z1510X0
Backblech, Alu
Z1330X0
Backblech Email
Z1340X0
Brotbackstein
Z1910X0
Nachrüstsatz Clou4/Kat.
Z1750X0
Auflaufform
Z1270X0
Nachruestsatz Clou
Z1740X0



1) 18 1054
V01
18 1066
V02



- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01
- 16 7262
- V02
- 4) 17 1574
- V01
- 17 1615
- V02
- 5) 36 5428
- V01
- 36 5430
- V02



1) 02 5876
2) 16 0916