





Gebrauchsanweisung
58 6065
(de,fr)


Zubehör:

Dampfgarer
N8640X2


Grillpfanne u. Bratrost
Z1230X2
Back,- u. Bratrost
Z1430X0
Bratenblech
Z1510X2
Backblech, Alu
Z1330X0
Backblech Email
Z1340X2
Brotbackstein
Z1910X0
Nachrüstsatz Clou4/Kat.
Z1750X0
Auflaufform
Z1270X2
Nachruestsatz Clou
Z1740X0



1) 06 9762
 V01, V03
 15 4845
 V02, V04



- 1) 15 4762
- 2) 15 4763
V01, V02
17 2646
V03, V04
- 3) 16 2555
- 4) 17 1574
V01, V03
17 1615
V02, V04
- 5) 16 7255
V01
16 7262
V02
18 2612
V03
18 2427
V04



- 1) 41 8562
- 2) 17 1146