




Libro de instrucciones
51 8302
(E, GB, F, P, D, NL)

Cjto. transformación
gas natural
15 5265

Cjto. transformación
gas butano
15 9769


Cjto. transformación
gas ciudad
15 9798

1) 15 9770
V01, V02
16 5347
V03, V04, V05

2) 15 9783
V01, V02
16 5345
V03, V04, V05

3) 15 9772
V01, V02
16 5349
V03, V04, V05

4) 15 9785
V01, V02
16 5346
V03, V04, V05



1) 29 5079
2) 29 5080