








Libro de instrucciones
58 0143
(es,pt)

1) 28 3495





- 1) 16 2577
- 2) 03 4102
- 3) 03 3957



- 1) 41 9193
V01
41 9194
V02
- 2) 06 7929
V01
06 7938
V02
- 3) 06 7927
V01
06 7935
V02
- 4) 15 2684
V01
16 2224
V02

Cjtos transformación:
Gas Butano
15 3164
Gas Natural
15 3165