





Ident-Nummern-Konstante
3740


51 1375 bis FD 6604
51 2817 ab FD 6605
EU1
Gebrauchsanweisung
(D,GB,F,I,NL,E)
51 2277
Aufstellanleitung

- 1) 04 2085 Set
- 2) 04 2105 Set
- 3) 01 9177 Set
- 4) 02 5122
- 5) 02 5123
- 6) 02 5657 rot
- 7) 02 5658 grün
- 8) 02 5824
- 9) 02 7950
- 10) 08 4059 bis FD 6604
08 5079 ab FD 6605

Ident-Nummern-Konstante
3740




- 1) 08 0781 Set
- 2) 02 5067 Set
- 3) 01 9204 Set
- 4) 20 1073 EU1
20 2256 J1
- 5) 05 1838



**BOSCH**

SMS 6112 — 0 730 101 636—EU1, ab FD 6603

GESCHIRRSPÜLGERÄTE
Standgeräte

**BOSCH**

SMS 6112 — 0 730 101 636—EU1

GESCHIRRSPÜLGERÄTE
Standgeräte