





51 1424/00
 EU1, F1
 Gebrauchsanweisung
 (D, GB, F, I, NL, E)



TECHNISCHE DATEN / TECHNICAL DATA / DONNÉES TECHNIQUES

Verdichter/Compressor/Compresseur		Danfoss				
Typ/Type		TL 5 A				
Förderleistung/Delivery/Débit	l/h	920				
Anlaufstrom/Starting current/Cour. de démarrage	A	9				
Widerstand/Resistance/Résistance	Ha/main/prin.	Ω 15,7				
	Hi/aux	Ω 18,8				
Temp.-Regler/Thermostat		M + J				
Typ/Type		TF 5/				
Reglerstellung/Position		kalt	warm			
Schaltwerte/Switching values/	„ein“	+ 4	+ 4			
Valeurs de commutation	„aus“	- 30	- 15			
	(„abtauen“ od.)	„alarm“				
Füllmenge/Fill quantity/Charge	R12	g	140			
Anschlußwert/Conn. load/Puiss. connectée		W	120			
Heizung/Heater/Chauffage						
Widerstand/Resistance/Résistance	Ω					
Leistung/Power/Puissance	W					
Ventilator/Blower/Ventilateur						
Widerstand/Resistance/Résistance	Ω					
Magnetventil/Magnetic valve/Electrovanne						
Widerstand/Resistance/Résistance	Ω					
Spannung/Voltage/Tension	V					

Pos.	EU1,F1,EU2,F2		
1	Danfoss		
2	14 0065/45		
3	02 0108/26		
4			
5	02 1361/04		
6	05 1413/06		
7			
8	11 0437/04		
9	05 0166/05		
10			
11	11 1243/01		
12			
13			
14			