


BBS6312/04 – V01, schwarz
 BBS6312/06 – V02, schwarz
 BBS6318GB/04 – V03, schwarz
 BBS6318GB/06 – V04, schwarz

BBS6318GB/05 – V05, schwarz
 BBS6312/07 – V06, schwarz
 BBS6318GB/07 – V07, schwarz
 BBS6312/09 – V08, schwarz




Mat. – Nr. – Konstante
 3740
 Gebrauchsanweisung
 58 0629
 (de, en, fr, it, nl, es, pt, el,
 da, sv, fi, no, tr)
 52 4170

Zubehör:
 Accu-Bürste
 BBZ37AB/01
 Turbo-Bürste
 BBZ28TB

BBS6312/04 – V01, schwarz
 BBS6312/06 – V02, schwarz
 BBS6318GB/04 – V03, schwarz
 BBS6318GB/06 – V04, schwarz

BBS6318GB/05 – V05, schwarz
 BBS6312/07 – V06, schwarz
 BBS6318GB/07 – V07, schwarz
 BBS6312/09 – V08, schwarz



Mat. – Nr. – Konstante
 3740

BBS6312/04 – V01, schwarz
BBS6312/06 – V02, schwarz
BBS6318GB/04 – V03, schwarz
BBS6318GB/06 – V04, schwarz

BBS6318GB/05 – V05, schwarz
BBS6312/07 – V06, schwarz
BBS6318GB/07 – V07, schwarz
BBS6312/09 – V08, schwarz

Mat. – Nr. – Konstante
3740

